






# Change Trailers



1 Remove the attached trailer

2 Scroll down to Add Trailers button

3 Select the new trailer and finish inspection



From the inspection shown in the vehicle details page, select +/- Trailers. You can see the trailer that is attached. Select "Change" to make a new Attached value of No.

Add a new trailer the same way the first trailer was added, do the trailer inspection (embedded in vehicle inspection), and then review and save. Now you can see the new trailer, and also still see the detached trailer.